

# Two Piece Boxes

1. Lay the box base flat with short end facing you.
2. Prepare the short side by first folding the small wing tabs 90 degrees down.
3. Fold the scored edge 90 degrees down.
4. Using your index fingers and thumbs, fold-up one end of the long sides simultaneous with the prepared short side.
5. Tuck short edge down until the small wing tabs sit in place.
6. Repeat for the other side.
7. Install Crystal Clear Slip Cover or Crystal Clear Top Cover.



